

Схемы установки штапиков

5106
5186
5256
5257
5258
5259
5260
5431
5499
5530




Рис. 1

5114
5266
5267
5268
5269




Рис. 2

5267
5114
5268
5269




Рис. 3

